

# **ELECTRIC MACHINES – UNIPLAN – 3.5 kW**



# **EXCITATION RHEOSTAT**



# **DL 2044**

Suitable for the series excitation of the direct current machines.

#### **EXCITATION RHEOSTAT**

#### **DL 2066RHE**

Cursor linear rheostat for the excitation of the synchronous machine.


# STARTING AND SYNCHRONIZATION UNIT



#### **DL 2053RHD3**

Starting rheostat for DL 2053A and synchronization device with mains frequency. Possibility to use the motor as synchronous generator if driven by a motor.


# **STAR/DELTA STARTER**



#### **DL 2035**

Star/delta starter for the three-phase squirrel-cage induction motors

# **POLE CHANGING UNIT**



# **DL 2036**

Switch to change the number of poles in Dahlander type motors.